

Your Global Automation Partner

TURCK

excom I/O System

Integrating the excom System in DeltaV

Integration Manual



Contents

1	About This Manual	5
1.1	Target groups.....	5
1.2	Explanation of symbols used	5
1.3	Other documents	6
1.4	Feedback about these instructions.....	6
2	Notes on the System	7
2.1	System identification.....	7
2.2	Manufacturer and service	7
3	For Your Safety	8
3.1	General safety notes	8
3.2	Notes on Ex protection.....	8
4	Integrating the excom System in DeltaV via PROFINET	9
4.1	Requirements	9
4.1.1	Requirements – hardware	9
4.1.2	Requirements – software	10
4.2	excom – assigning the IP address and PROFINET name	10
4.2.1	Setting the IP address.....	10
4.2.2	Assigning a PROFINET device name	11
4.3	Installing an GSDML file	12
4.4	Creating an excom station.....	15
4.5	Setting up the DeltaV controller	16
4.6	Connecting the excom station to a virtual PROFINET card	20
4.7	Setting excom PROFINET parameters	34
4.8	Parameterizing excom communication.....	35
4.9	Parameterizing excom modules.....	37
4.9.1	Example: DM80.....	37
4.9.2	Example: DO40	39
4.9.3	Example: AIH40.....	40
4.9.4	Example: AOH40.....	42
4.10	Configuring I/O data	43
4.11	PROFINET diagnostics	49
5	Redundancy Strategies	51
5.1	Topology	51
5.2	Redundancy setup	51
5.3	System redundancy	52

1 About This Manual

This manual describes the integration of the excom system in the DeltaV control system via PROFINET.

Read this manual and the applicable documents carefully before the integration. This will prevent the risk of personal injury and damage to property. Keep this manual safe during the service life of the product. If the product is passed on, hand over this manual as well.

The manual describes the possibilities for the GSDML-based integration, from the installation of the GSDML right through to the handling of the I/O data and the associated diagnostics. Other applications of the excom system are described in addition to the general integration:

- Setting up redundancy
- Changing parameters during operation
- Changing configurations during operation








1.1 Target groups

These instructions are written for suitably qualified and trained personnel and must be read carefully by anyone entrusted with the mounting, commissioning, operation, maintenance, disassembly or disposal of the device.

When using the device in Ex circuits, the user must also have an additional knowledge of explosion protection (EN 60079-14 etc.).

1.2 Explanation of symbols used

The following symbols are used in these instructions:

	DANGER DANGER indicates a dangerous situation with high risk of death or severe injury if not avoided.
	WARNING WARNING indicates a dangerous situation with medium risk of death or severe injury if not avoided.
	CAUTION CAUTION indicates a dangerous situation of medium risk which may result in minor or moderate injury if not avoided.
	NOTICE NOTICE indicates a situation which may lead to property damage if not avoided.
	NOTE NOTE indicates tips, recommendations and useful information on specific actions and facts. The notes simplify your work and help you to avoid additional work.
	CALL TO ACTION This symbol denotes actions that the user must carry out.
	RESULTS OF ACTION This symbol denotes relevant results of actions.

1.3 Other documents

Besides this document the following material can be found on the Internet at www.turck.com:

- Data sheets
- Quick start guides
- excom manuals
- GEN... Getting Started
- Approvals

1.4 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to techdoc@turck.com.

2 Notes on the System

2.1 System identification

This manual applies to the Turck excom system.

2.2 Manufacturer and service

Hans Turck GmbH & Co. KG
Witzlebenstraße 7
45472 Mülheim an der Ruhr
Germany

Turck supports you with your projects, from initial analysis to the commissioning of your application. The Turck product database contains software tools for programming, configuration or commissioning, data sheets and CAD files in numerous export formats. You can access the product database at the following address: www.turck.de/products

For further inquiries in Germany contact the Sales and Service Team on:

- Sales: +49 208 4952-380
- Technology: +49 208 4952-390

Outside Germany, please contact your local Turck representative.

3 For Your Safety

The product is designed according to state-of-the-art technology. However, residual risks still exist. Observe the following warnings and safety notices to prevent damage to persons and property. Turck accepts no liability for damage caused by failure to observe these warning and safety notices.

3.1 General safety notes

- The device may only be assembled, installed, operated, parameterized and maintained by professionally-trained personnel.
- The device may only be used in accordance with applicable national and international regulations, standards and laws.
- The device only meets the EMC requirements for industrial areas and is not suitable for use in residential areas.

3.2 Notes on Ex protection

- Only use the device in Ex areas when installed in the appropriate protective housing.
- Observe national and international regulations for explosion protection.
- When using the device in explosion-protection circuits, the user must have a working knowledge of explosion protection (EN 60079-14 etc.).
- Use the device only within the permissible operating and ambient conditions (see approval data and Ex approval specifications).
- Fit blank modules (BM1) on unused slots on the module rack.
- Cables and terminals with intrinsically safe circuits must be indicated – use light blue for color-coding. Separate cables and terminals from non-intrinsically safe circuits or isolate accordingly (EN 60079-14).
- Perform "Proof of intrinsic safety".
- Never connect equipment to intrinsically safe circuits if this equipment was previously used once in non-intrinsically safe circuits.

4 Integrating the excom System in DeltaV via PROFINET

The integration of the excom system in the DeltaV control system is GSDML-based. The following describes all the steps required for the GSDML installation right through to the handling of I/O data and diagnostics.

4.1 Requirements

4.1.1 Requirements – hardware

This example uses the following hardware:

DeltaV hardware

- DeltaV MD controller
- DeltaV virtual I/O module 2 of the M Series (VIM2)

Turck hardware

- MT08-N module rack
- Gateway GEN-N
- DM80-N digital input/output module
- DO40-N digital output module
- AIH401-N analog input module
- AOH401-N analog output module
- Ethernet cable




Fig. 1: Example setup of the excom station

4.1.2 Requirements – software

This example uses the following software:

DeltaV software



NOTE

VIMNet Explorer V9.4 or higher is required to set up the virtual I/O module with PROFINET.

- DSC DeltaV V11.3.1 (DeltaV Explorer)
- VIMNet Explorer V9.6.1.5

Turck software

- GSDML file V2.3
- Gateway firmware V1.3.0
- Turck Service Tool

4.2 excom – assigning the IP address and PROFINET name

4.2.1 Setting the IP address

The device is factory set to IP address 192.168.1.254. A PROFINET device name has not yet been assigned. The IP address can be set via the Turck Service Tool, the DTM or the web server. The following example shows the setting of the IP address via the Turck Service Tool. The Turck Service Tool can be downloaded free of charge at www.turck.com.



NOTE

The PC and the gateway must be located in the same IP network.

- ▶ Connect the device to a PC via the Ethernet interface.
- ▶ Launch the Turck Service Tool.
- ▶ Click **Search** or press [F5].
- ⇒ The Turck Service Tool displays the connected devices.

Turck Service Tool, Vers. 3.2.2

Your Global Automation Partner **TURCK**

Search... (F5) Change (F2) Wink (F3) Actions (F4) Clipboard Language EN Expert view ON Start DHCP (F6) EIP Configuration (F7) ARGEE (F8) BEEP (F9) Close Columns

No	MAC address	Name	IP address	Netmask	Gateway	Mode	Device	Version	Adapter	A...	Pr...	Ke...	BE...	Turck...
1	00-07-46-84-08-4F		10.17.110.138	255.255.255.0	10.17.110.1	PGM_DHCP	TN-UHF-Q300-EU-CDS	1.1.1.9	10.17.110.25	-	-	-	-	Turck
2	00-07-46-84-19-07		192.168.1.254	255.255.255.0	0.0.0.0	PGM_DHCP	GEN-N	1.2.6.0	192.168.1.95	-	-	-	-	Turck

Found 2 Devices.

Fig. 2: Turck Service Tool

- ▶ Click the gateway (example: **GEN-N**).
- ▶ Click **Change** or press [F2].
- ▶ Set the IP address and if necessary the network mask and gateway.
- ▶ Accept the changes by clicking **Set in device**.




Fig. 3: Setting the IP address

4.2.2 Assigning a PROFINET device name

A PROFINET device name must be assigned in order to identify the excom system. The PROFINET device name is set in the Turck Service Tool.

Observe the following requirements for assigning the PROFINET name:

- Numbers between 0...9
- Lower case letters from a...z
- Dashes "-" and dots "."
- Max. 63 characters in succession without permissible special characters "-" and "."
- Max. 127 characters
- Spaces not allowed
- "Port (0...999)" not allowed
- Starting with a number not allowed
- Number (sequences) similar to IP addresses not allowed (n.n.n.n (n = 0 to 9))
- Dashes "-" and dots "." at the beginning or end not allowed

Alternatively, the PROFINET device name can be set at **Gateway Configuration** in the web server.

- ▶ Click the empty field under **Name** in the Turck Service Tool.
- ▶ Assign a device name.
- ▶ Click **Set in device**.




Fig. 4: PROFINET device name

4.3 Installing an GSDML file

The GSDML file is available as a Zip file free of charge for download from www.turck.com.

- ▶ Unpack the zip file.

Proceed as follows to install the GSDML file:

- ▶ Open **DeltaV Explorer**.
- ▶ Choose **Applications** → **VIMNet Explorer**.
- ▶ Alternatively: Click the **VimNet Explorer** icon in the toolbar.




Fig. 5: Open VimNet Explorer

- ⇒ The **New VIO Document** window opens.

- ▶ Right-click **PROFINET Definition Library**.
- ▶ Click **Add Connection Definition**.




Fig. 6: PROFINET Definition Library – Add Connection Definition

- ⇒ A window opens, in which the GSDML file can be selected.

- ▶ Select the GSDML file.
- ▶ Click Open.




Fig. 7: Opening the GSDML file

- ⇒ The GSDML file is installed.
- ⇒ The excom modules and their parameters appear in the GSDML_Edit window → VIM Mapping.

4.4 Creating an excom station

The excom station must be configured. For this map the physical setup of the excom station in DeltaV. The order of the slots must match the order of the modules in the excom station.



NOTE

A template name can be assigned at **Definition Name**. If no name is assigned, the template contains the name of the GSDML file.

- ▶ Open the **GSDML_Edit** window → press **VIM Mapping**.
- ▶ Select the required module type at **Available Modules** → **Category**.
- ▶ Select the relevant excom gateway variant at **Access PT**.
- ▶ Search for the modules of the excom station.
- ▶ At **Selected Modules** drag the modules to the appropriate slot.




Fig. 8: Mapping the virtual excom station in DeltaV

4.5 Setting up the DeltaV controller

The DeltaV controller must be set up in order to configure the excom station as a slave. The DeltaV controller must be integrated in the physical network of the VIMNet Explorer.



NOTE

The devices are identified by the controller name.

- ▶ Assign the same controller name for the same device (here: **CTLR-011290**) in both software environments.

- ▶ Choose **Physical Network** → Right-click **I/O Net**.
- ▶ Click **New Controller**.




Fig. 9: Clicking **New Controller**

- ⇒ The **Controller** window is opened.

- ▶ Assign the controller name. (The controller must have the same name as in the DeltaV Explorer.)
- ▶ Confirm the entry with **OK**.




Fig. 10: Assigning the controller name

⇒ The controller appears in the project tree (here: **CTRL-011290**).

Adding a VIM-PROFINET master

- ▶ Right-click the controller (here: **CTRL-011290**).
- ▶ Click **New IO VIM**.




Fig. 11: Clicking New IO VIM

- ⇒ The **ADD PROFINET Virtual I/O Module** window opens.

- ▶ Set up the PROFINET master.
- ▶ Confirm the settings with OK.




Fig. 12: Setting up the PROFINET master

4.6 Connecting the excom station to a virtual PROFINET card

To connect the excom station to the PROFINET master it must be set up using the GSDML file.

- ▶ Right-click the appropriate virtual PROFINET card (here: C57 → P01).
- ▶ Click **Add Connection**.




Fig. 13: Clicking Add Connection

- ⇒ The **PROFINET Connection** window is opened.

- ▶ Select the excom station configured with the GSDML file in the drop-down menu via **Library Definition** → **Name**.




Fig. 14: PROFINET Connection window

- ▶ Click **Add** in the PROFINET Connection window.




Fig. 15: Opening the PROFINET Device Definition window

- ⇒ The PROFINET Device Definition window is opened.

In order for the excom station to communicate with the DeltaV PROFINET master, it must be assigned a PROFINET name and an IP address [▶ 11].

- ▶ Enter the PROFINET name (here: "turck-excom").
- ▶ Enter the IP address: (here: 10.4.0.2).
- ▶ Entering the subnet mask (here: 255.254.0.0).
- ▶ Confirm entries with **OK**.




Fig. 16: PROFINET – Assigning an IP address and name

The other parameters do not have to be set and are explained below:

Parameter	Meaning
Send Clock Time (ms)	The parameter (here:1 ms) is determined by the Send Clock Time (here: 32 μ s) multiplied by the basic time unit of 31.25 μ s defined in the PROFINET specification.
Reduction Factor	Reduction factor (see: Send Cycle Time (ms))
Send Cycle Time (ms)	The transfer interval is the product of Send Clock Time \times Reduction Factor. A Send Clock Time of 1 ms and a Reduction Factor of 64 means that IO data is sent every 64 ms.
Msg Per Second	Number of messages per second, which the excom station adds to the total message overhead of the VIM. The total message overhead is the right value at Total Devices.
Device Interval (ms)	Time between two messages from the excom station, the left value and between two messages for the VIM, the right value.
VLAN	VLAN-ID Only 0 is permissible for devices with the PROFINET IO specification V2.3.

Commissioning VIM

- ▶ Right-click VIM (here: **VIM01**).
- ▶ Click **Commission**.




Fig. 17: Opening the **Commission VIM** window

- ⇒ The **Commission VIM** window opens.

- ▶ Confirm with OK.




Fig. 18: Commission VIM window

Adding an excom station as a slave

The configuration must be loaded in the VIM:

- ▶ Right-click VIM (here: **VIM01**).
- ▶ Choose **Upload Configuration to VIM**.




Fig. 19: Loading the configuration in the VIM

- ▶ Save the document: Confirm the **PPV** window with **Yes**.




Fig. 20: PPV window

- ▶ Confirm the **VIM Configuration Upload** window with **OK**.




Fig. 21: Upload of the configuration completed

Exporting the FHX file

After the configuration has been successfully uploaded, the FHX file must be exported. This can be done in two ways:

1. Exporting an individual virtual card (here: **C57**).
2. Export all four virtual cards.

To export the individual virtual card:

- ▶ Right-click **C57**.
- ▶ Choose **Export FHX File**.




Fig. 22: Right-clicking an individual card

- ▶ Define the file name and memory location in the **Save As** window.
- ▶ Save the setting with **Save**.




Fig. 23: Defining the file name and memory location

- ▶ Confirm the prompt in the **Configure FHX Export Parameters** window without changes with **OK**.




Fig. 24: Confirming the window

To export all four virtual cards:

- ▶ Right-click VIM (here: **VIM01**).
- ▶ Choose **Export FHX File**.




Fig. 25: Right-click VIM01

- ▶ Define the file name and memory location in the **Save As** window.
- ▶ Save the setting with **Save**.




Fig. 26: Defining the file name and memory location

- ▶ Confirm the prompt in the **Configure FHX Export Parameters** window without changes with **OK**.




Fig. 27: Confirming the prompt

The file must then be loaded in the DeltaV Explorer.

- ▶ Choose **File** → **Import** → **Standard DeltaV Format...** in the DeltaV Explorer.




Fig. 28: Import in the DeltaV Explorer

- ▶ Select the required file in the **Import** window.
- ▶ Click **Open**.




Fig. 29: Importing a file

The new configuration must be loaded in the controller.



NOTE

Reload the configuration in the controller after each new configuration.

- ▶ Right-click **Physical Network**.
- ▶ Choose **Download** → **Physical Network** in the context menu.




Fig. 30: Loading the configuration in the controller

- ⇒ The configuration is loaded in the DeltaV controller.
- ⇒ The excom station is created as a slave.



NOTE

A configured excom station can be used as a template. Copy the station from the DeltaV Explorer and at **C57**, for example, insert → **P01**.

Exporting an excom station

The excom station can be exported for future applications.

- ▶ Right-click the excom station (here: EXCOM_02).
- ▶ Click **Export**.




Fig. 31: Exporting an excom station

- ▶ Assign memory location, name and file type.
- ▶ Click **Save**.




Fig. 32: Saving an export

- ⇒ The **Export complete** window appears.

4.7 Setting excom PROFINET parameters

The VIM mapping must be opened in order to set the gateway or module parameters:

- ▶ Open **VIMNet Explorer**.
- ▶ Right-click the excom station.
- ▶ Click **Properties**.
- ▶ Click **Edit** at **Library Definition**.
- ▶ Choose **excom GEN-N** under **Module**.
- ▶ Click **DAP v3.1** under **SubModule**.




Fig. 33: General PROFINET parameters

- ▶ Click the **Data** window on the right of the relevant parameters under **Records**.
- ▶ Select the parameter from the drop-down menu.

The index "gTid_510" consists of the general PROFINET parameters that are still without function:

Parameter	Value	Meaning
Deactivate all diagnostics	No	Diagnostics messages and alarms are generated.
	Yes	Diagnostics messages and alarms are not generated.
Deactiv. load voltage diagn.	No	The monitoring of the field power supply (from the gateway and the supply modules) is activated.
	Yes	Overshoots or undershoots of the field power supply are not indicated.
Deactivate I/O-ASS. Force Mode	No	–
	Yes	The DTM cannot access the gateway via Force mode.

4.8 Parameterizing excom communication

The VIM mapping must be opened in order to set the gateway parameters:

- ▶ Open **VIMNet Explorer**.
- ▶ Right-click the excom station.
- ▶ Click **Properties**.
- ▶ Click **Edit** at **Library Definition**.
- ▶ Click **Index** → **gTId_661**.
- ▶ The general settings appear under **Field** and **Data**.




Fig. 34: Gateway parameters

- ▶ Click the **Data** window on the right of the relevant parameters under **Records**.
- ▶ Select the parameter from the drop-down menu.

The index "gTId_661" consists of the following PROFINET parameters:

Parameter name	Value	Meaning
Module parameterization	Activate	The parameter is currently without function.
	Deactivate	If the parameter is activated, the module receives the parameter settings, e.g. from the controller, the IO supervisor or the DTM. Previous parameter settings are overwritten. If the parameter is deactivated, the module uses the saved parameters.
Line frequency	50 Hz 60 Hz	Select the filter for suppressing superimposed power supply interference with analog input signals.
Analog data format	Status MSB Status LSB No status	Select position of the status bit for analog input signals <input type="checkbox"/> Status MSB: Status bit at bit position 2 ¹⁵ <input type="checkbox"/> Status LSB: Status bit at 2 ⁰ <input type="checkbox"/> No status: Measured value without status bit
CAN redundancy	Off On	Activate or deactivate redundancy of internal communication between gateways and I/Os.
Redundancy mode	Off System redundancy	<input type="checkbox"/> No redundancy <input type="checkbox"/> Two gateways operate autonomously with the associated master.
Power supply	Single Redundant	Activate or deactivate diagnostic message of the redundant power supply.

4.9 Parameterizing excom modules

Different specific settings can be made via the parameter functions.

The VIM mapping must be opened in order to set the gateway or module parameters:

- ▶ Open **VIMNet Explorer**.
- ▶ Right-click the excom station.
- ▶ Click **Properties**.
- ▶ Click **Edit** at **Library Definition**.
- ▶ Select the appropriate module.
- ▶ Click the **Data** window on the right of the relevant parameters under **Records**.
- ▶ Select the parameter from the drop-down menu.

4.9.1 Example: DM80

The DM80 digital module is parameterized in the following example. The **Module parameterization** parameter is still without function.




Fig. 35: DM80 parameters

Parameter overview – DM80

The parameters are set in pairs for the particular two channels (1/2, 3/4, 5/6, 7/8).

The default parameter values are shown in the following table in **bold** type.

Parameter name	Value	Meaning
Short circuit detection	On Off	Activate or deactivate the short circuit monitoring in pairs The output signal can only be monitored if the output is activated.
Open line detection	On Off	Activate or deactivate the wire-break monitoring in pairs The output signal can only be monitored if the output is activated.
Failsafe mode	Min. value Max. value Last valid value	Set substitute value per channel: minimum (0), maximum (1) or last valid value (0 or 1)
Direction	Input Output	Activate or deactivate input or output Input: The channels of the module are switched in groups as inputs (1/2, 3/4, 5/6, 7/8). The DM80-N S and DM80-N S8I variants provide one status. Output: The channels of the module are switched as outputs in groups (1/2, 3/4, 5/6, 7/8). The DM80-N S variant on the other hand also provides a status for the outputs.
Polarity	Normal Inverse	Activate or deactivate signal inversion
Dumping	Off 10 ms 20 ms 50 ms	Activate or deactivate additional input signal damping
Channel 1...8	Active Inactive	Activate or deactivate channel 1...8 If a channel is not used it can be switched off to prevent unwanted error messages.

4.9.2 Example: DO40

The DO40 digital module is parameterized in the following example. The parameters are presented individually for each channel. The **Module parameterization** parameter is still without function.




Fig. 36: DO40 parameters

Parameter overview – DO40.

The default parameter values are shown in the following table in **bold type**.

Parameter name	Value	Meaning
Short circuit detection	On	Activating or deactivating the short circuit monitoring
	Off	The output signal can only be monitored if the output is activated.
Open line detection	On	Activating or deactivating the wire-break monitoring by channel
	Off	The output signal can only be monitored if the output is activated.
Failsafe mode	Min. value	Set substitute value per channel: minimum (0), maximum (1) or last valid value (0 or 1)
	Max. value	
	Last valid value	
Polarity	Normal	Activate or deactivate signal inversion
	Inverse	

4.9.3 Example: AIH40

The AIH40 analog module is parameterized in the following example. The **Module parameterization** parameter is still without function.




Fig. 37: AIH40 parameters

Parameter overview – AIH40

The default parameter values are shown in the following table in **bold** type. The module can be configured with 1, 4 or 8 HART values. Further information on this is provided in the excom manual for the non-Ex area.

Parameter name	Value	Meaning
Short circuit detection	On Off	Activate or deactivate short circuit monitoring
Open line detection	On Off	Activate or deactivate wire-break monitoring
Failsafe mode	Min. value Max. value Last valid value	Set substitute value per channel: minimum, maximum or last valid value
HART status/meas. range	Off/0...20 mA	Off/0...20 mA: Dead zero without HART status query; diagnostics for wire break and measuring range undershoot not possible
	Off/4...20 mA	Off/4...20 mA: Live zero without HART status query; diagnostics for wire break and measuring range undershoot active
	On/4...20 mA	On/4...20 mA: Live zero with HART status query; diagnostics for measuring range undershoot and overshoot as well as wire break and short circuit monitoring active
Filter (PT1)	Off 0,1 s 2,6 s 29,2 s	Activate or deactivate software filter for generating an average value

4.9.4 Example: AOH40

The AOH40 analog module is parameterized in the following example. The **Module parameterization** parameter is still without function.




Fig. 38: AOH40 parameters

Parameter overview – AOH40

The default parameter values are shown in the following table in **bold** type. The module can be configured with 1, 4 or 8 HART values. Further information on this is provided in the excom manual for the non-Ex area.

Parameter name	Value	Meaning
Short circuit detection	On Off	Activate or deactivate short circuit monitoring
Open line detection	On Off	Activate or deactivate wire-break monitoring
Failsafe mode	Min. value Max. value Last valid value	Set substitute value per channel: minimum, maximum or last valid value
HART status/meas. range	Off/0...20 mA Off/4...20 mA On/4...20 mA	Define HART status / measuring range Off/0...20 mA: Dead zero without HART status query and wire break inactive Off/4...20 mA: Live zero without HART status query and wire break active On/4...20 mA: Live zero with HART status query (HART diagnostics active) and wire break active

4.10 Configuring I/O data

The **VIMNet Explorer** configures the PROFINET mapping independently. The GSDML file defines how the data from the PROFINET device is to be interpreted. During the configuration of the excom system the GSDML file automatically creates signals for each I/O module. The following figure shows the automatic configuration of the I/O signals using the example of a DM80 module:

- ▶ Open **VIMNet Explorer**.
- ▶ Click **VIM Mapping**.
- ▶ Select the module at **Selected Modules** (here: **DM80**).
- ▶ Click **IO Data**.




Fig. 39: Configuring I/O data



NOTE

The PROFINET buffer consists of the I/O data and the IOCS and IOPS together. The IO Consumption Status (**IOCS**) reports to the module that generated the I/O data whether it was used or not. The IO Production Status (**IOPS**) is used by the producing module to monitor the quality of the associated I/O data.

The VIMNet Explorer uses the GSDML file to map the PROFINET data automatically in the excom system. The PROFINET device is mapped in the signals of the PROFIBUS device. Each PROFIBUS device in DeltaV contains a set of slots that each contain a set of signals. The description for each PROFINET device is part of the associated GSDML file. The GSDML files also describe the arrangement of the data in the I/O buffer.

The VIM virtual I/O module maps the I/O buffer in a series of PROFIBUS devices in DeltaV. The maximum size of a PROFINET buffer is 1440 bytes. One buffer is provided for the input data and one for the output data.

The I/O buffer of a PROFINET device mapped in DeltaV can take a maximum of 512 bytes (256 inputs and 256 output bytes), which are divided up into 128-byte slots with 64 inputs and 64 outputs. The VIM virtual I/O module divides up the PROFINET buffer automatically and assigns all parts of the PROFINET data buffer to a PROFIBUS slot. The buffer is distributed so that a specific signal (defined in the GSDML file) is not split by the slot boundaries.

Adding an I/O signal manually

A signal can also be added manually. This is illustrated here using the DM80 as an example. The DeltaV Explorer must be opened:

- ▶ In the project tree under **System Configuration** → **Physical Network** → **Control Network** → **CLTR-011290** → open **C57**.
- ▶ Choose **C57PB42** → **SLOT001** in the subtree.
- ▶ Right-click **SLOT001**.
- ▶ Click **New Profibus Signal**.
- ▶ Set the **Signal direction** to **Input** in the **New Profibus Signal** window.
- ▶ Select the data type under **Data type**.
- ▶ Confirm selection with **OK**.




Fig. 40: Creating the I/O signal manually

Placing a tick next to **Use diagnostic channel** makes it possible to link a signal to a channel-specific diagnosis.




Fig. 41: Linking a signal to channel-specific diagnostics

The changes must be loaded in the DeltaV controller. The DeltaV Explorer displays a blue triangle if this is necessary. If changes were made to the setup data, this is indicated at the nodes. Proceed as follows in order to load the configuration in DeltaV:

- ▶ Right-click **Physical Network**.
- ▶ Choose **Download** → **Physical Network**.




Fig. 42: Loading changes in the controller

- ▶ Confirm the **Confirm Total Download** window with **Yes**.




Fig. 43: Confirming a download

- ▶ Click **Close** to close the **Download complete** window.

4.11 PROFINET diagnostics

Diagnostics options are available for the VIM card, the DeltaV I/O card as well as for the field devices. This example shows diagnostics for the VIM card:

- ▶ Right-click VIM (here: **VIM01**).
- ▶ Click **Diagnose**.




Fig. 44: Diagnostics

- ▶ Right-click the VIM again in the new window that appears (here: **VIM01**).
- ▶ Click **Enable VIM Communications** in the context menu to switch to Online View.




Fig. 45: Enable VIM Communications

⇒ The diagnostics are displayed for the individual slots (here: **Slot 3** → **SubSlot 1**).




Fig. 46: Diagnostics window

AR in the diagnostics window displays the status of the PROFINET Application Relation.
CR displays the Connection Relations status.

5 Redundancy Strategies

5.1 Topology

The general topology of the Turck-specific system redundancy with the Ethernet protocols EtherNet/IP, Modbus TCP and PROFINET is structured as follows:




Fig. 47: System redundancy with one master and two gateways




Fig. 48: System redundancy with two masters and two gateways

The system redundancy with one master and two gateways is a Turck-specific, parameterizable redundancy function of the excom system. The two gateways are provided here with separate IP addresses. The separate IP addresses are used to set up independent communication. The gateways communicate the input data and receive the output data via the IP addresses. One gateway is the primary gateway while the second gateway acts as a backup. If the primary gateway fails, a bumpless switchover to the backup gateway is carried out automatically. The redundancy function makes it possible to implement interruption-free communication. The output word of the gateway enables the forcing of a redundancy switchover.

When system redundancy is implemented with two masters and two gateways, two independent Ethernet masters communicate with the associated gateway. Both masters can be controlled via one or two process control system controllers. There are two independent Ethernet connections to the excom system, in order to process the process data.

5.2 Redundancy setup



NOTE

Both gateways must have the same configuration, parameterization and firmware.

The **Redundancy mode** gateway parameter must be set for **system redundancy**.

5.3 System redundancy



NOTE

Both gateways must have the same configuration, parameterization and firmware.

If the **Redundancy mode** parameter is set to **system redundancy** in the DTM, web server or control system, the excom station operates in system redundancy mode. Both gateways communicate with their respective master. The PRIO LED is lit on the active gateway. The active gateway takes over the output data transferred by the master and sends this to the output modules.

The gateway communicating with the secondary master ignores the received output data as the secondary module does not have write access to the output modules.

If the gateway is configured in the controller as "GEN... C", the gateway is provided with an input word as well as an output word for monitoring redundancy. The input word describes the current state of the gateway.

The output word is used for the manual redundancy switchover in the master. It is possible to switch in the process control system from the primary gateway to the secondary gateway. A switchover is carried out in response to the following events:

- The primary gateway was removed.
- Communication to the primary gateway was interrupted.

After a switchover, an automatic switchover to the former primary gateway is no longer carried out.

When the excom system is started, the gateway on the left starts to operate as the primary gateway. If communication with the left gateway fails, the gateway on the right tries to establish primary communication.

Assignment of gateway process data bits

The input word of the gateway process data is used to view the gateway and system redundancy of the excom station:

Byte	Bit							
	7	6	5	4	3	2	1	0
0	Not used			Left power supply unit	Right power supply unit	Gateway redundancy	Slot	Active/passive
1	Not used							

Meaning of the gateway process data bits

Designation	Meaning
Left power supply unit	0: Left power supply unit not present
	1: Left power supply unit fitted
Right power supply unit	0: Right power supply unit not present
	1: Right power supply unit fitted
Gateway redundancy	0: Redundant gateway or redundant communication not available
	1: Redundancy available
Slot	0: Gateway is located on the right slot (GW2)
	1: Gateway is located on the left slot (GW1)
Active/ passive	0: Gateway is passive
	1: Gateway is active

Assignment of the command bits

The output word of the gateway enables the forcing of a redundancy switchover in the "Red switching" web server:

Byte	Bit							
	7	6	5	4	3	2	1	0
0	Not used					Control bit	Redundancy switchover is initiated	Activation of the right or left gateway
						Control bits for edge change		
1	Not used							

Meaning of the command bits

Designation	Meaning
Bit 2 = 0 Redundancy switchover is initiated	11 → 01: Receiver is the passive gateway. The passive gateway requests control from the active gateway and becomes active.
	11 → 10: Receiver is the active gateway. The active gateway gives control to the passive gateway and becomes passive.
Bit 2 = 1 Activation of the right or left gateway	11 → 01: Receiver is the left gateway. The left gateway requests control from the right gateway and becomes active.
	11 → 10: Receiver is the right gateway. The right gateway requests control from the left gateway and becomes active.

TURCK

Over 30 subsidiaries and over
60 representations worldwide!

100016756 | 2020/03



www.turck.com