# SD50 with IO-Link Status Display Product Manual



Original Instructions p/n: 242037 Rev. B 23-Jan-25 © Banner Engineering Corp. All rights reserved.

### Contents

Chapter 1 Features	<b>3</b>
Chapter 2 Wiring	4
Chapter 3 IO-Link Process Data Out (Master to Device)	5
Chapter 4 Specifications	11
FCC Part 15 Class A for Unintentional Radiators Industry Canada ICES-003(A)	
Dimensions	
Chapter 5 Accessories	
Cordsets	
Mounting Brackets	
Chapter 6 Product Support and Maintenance	
UTF-8 Encoding Table and Unicode Characters	
Clean with Mild Detergent and Water	
Repairs	
Contact Us Banner Engineering Corp Limited Warranty	
Damer Lingineening Corp Linneed Warranty	

Models .....

### Chapter 1

### **Features**

Provide More Status Information in the Most Helpful Locations



• Easily configurable, versatile display can be installed nearly anywhere, making it a simple yet powerful alternative to complex HMIs and other displays

- Great for displaying takt time, equipment status, assembly sequences, counts, and measurements where they are most useful
- Discrete and IO-Link models integrate into many different systems and applications, especially Banner sensing, safety, and monitoring solutions
- Quick and easy configuration—simply define the desired text and call it via discrete control or process data
- Bright white LED display and multicolored status LEDs legible from 10 meters away inform operators about exactly what is going on so they can respond quickly and accurately
- IP65-rated polycarbonate housing resists impact and condensation to provide clear communication in challenging and changing environmental conditions

### Models

#### Model Key

Series	Height	Style	Display Length	Display Text Color	Control	Connector <sup>(1)</sup>
SD	50	Р	300	w	к	QP
Status Display	50 mm height	P = Pro	300 = 300 mm	W = White	K = IO-Link	QP = 150 mm (6 in) PVC-jacketed cable with a 4-pin M12 male quick- disconnect connector

<sup>&</sup>lt;sup>(1)</sup> Models with a quick-disconnect connector require a mating cordset.





SD50 with IO-Link Wiring

4-Pin Male M12 Pinout	Pinout Key and Wiring
	<ol> <li>Brown - 12 V DC to 30 V DC</li> <li>White - Not used</li> <li>Blue - DC Common</li> <li>Black - IO-Link Communication</li> </ol>



## IO-Link Process Data Out (Master to Device)

IO-Link® is a point-to-point communication link between a master device and a sensor and/or light. It can be used to automatically parameterize sensors or lights and to transmit process data. For the latest IO-LINK protocol and specifications, please visit www.io-link.com.

For the latest IODD files, please refer to the Banner Engineering Corp website at: www.bannerengineering.com.

#### Parameter Data

Use Banner's IO-Link Master to configure the Parameter Data, which can configure the device's mode, display settings, and custom configurations.

DXMR90-4K SD	MR90-4K SD50P300WKQP (1)					
Generic Process Data Parameters	neric cess Data Read Brown					
	Parameters				٩	
	Command Name	R/W	Val	Cmd State	Units	
	▶ Parameters: Additional Settings					
	Parameters: Custom Color 1 Configuration					
	Parameters: Custom Color 2 Configuration					
	Parameters: Device Access Locks					
	Parameters: Display Settings					
	Parameters: Executable Commands					
	Parameters: Measure Base Settings					
	Parameters: Mode Settings					
	Parameters: Message Mode Message Settings					
	Parameters: Message Mode Message Settings Continued					
	Parameters: Mode Selection					
	Parameters: Threshold 1 Settings					
	Parameters: Threshold 2 Settings					
	Parameters: Threshold 3 Settings					
	Parameters: Threshold 4 Settings					
	Parameters: Timer Mode Settings					

### Mode

Select the mode for the device: Run Mode (default setting), Message Mode, Measure Mode, Timer Mode, Counter Mode, or Demo Mode.

A Parameters: Mode Selection		
Operating Mode Selection	rw	Timer Mode

### **Additional Settings**

Use Additional Settings to set the Indicator Intensity, Flash Rate, Display Intensity, and Scroll Speed to custom values that are unique from the standard options.

Command Name	R/W	Val		
A Parameters: Additional Settings				
Additional Settings.Custom Intensity (0 - 100%)	rw	100		
Additional Settings.Custom Flash Rate (0.5 - 20)	rw	1.5		
Additional Settings.Custom Display Intensity (0 - 100%)	rw	100		
Additional Settings.Custom Display Scroll Speed (0 - 255)	rw	15		

### **Custom Color Configuration**

Use Custom Color Configuration to control the colors of the indicator LEDs using RGB codes ranging from 0-255.

Custom 1.Red	rw	255	
Custom 1.Green	rw	255	
Custom 1.Blue	rw	255	

### **Device Access Locks**

Use Device Access Locks to lock or unlock Parameter Write Access and Data Storage Access.

-	Parameters: Device Access Locks				
	Device Access Locks.Parameter Write Access	rw	Unlocked		
	Device Access Locks.Data Storage	rw	Unlocked		

### **Display Settings**

Use Display Settings to configure the color, intensity, direction, speed, scroll mode, orientation, and justification of the display text.

General Settings	Description	
Display Text Color	Select either white or black display text.	
Display Intensity	Define the intensity of the display text with a set of preset values or a custom value.	
Display Control Direction	Select the direction the display text scrolls, using the connector as a reference.	
Display Scroll Speed	Define the speed at which the display text scrolls using a set of preset values or a custom value.	
Display Scroll Mode	Determine if the device scrolls the text. Auto scrolls the text for inputs longer than 16 characters.	
Display Orientation	Select the orientation of the device, using the connector as a reference. The text and display rotate to match the device's orientation.	
Display Justification	Select the justification of the display text between Left, Right, or Center.	

### **Restore Factory Settings**

Use Restore Factory Settings to clear the current configurations and reset the device to its initial settings.

### Measure Base Settings

Use Measure Base Settings to configure the overall settings of the display device in Measure Mode.

A Parameters: Measure Base Settings			
Measure Base Configuration.Display Override	rw	Disabled	
Measure Base Configuration.Override string	rw	Base	
Measure Base Configuration.Animation	rw	Off	
Measure Base Configuration.Color 1	rw	Green	
Measure Base Configuration.Color 1 Intensity	rw	High	
Measure Base Configuration.Speed	rw	Standard	
Measure Base Configuration.Pulse Pattern	rw	Normal	
Measure Base Configuration.Color 2	rw	Green	
Measure Base Configuration.Color 2 Intensity	rw	High	

General Settings	Description	
Display Override	Determine if the device displays a string of text rather than the output values.	
Override String	Determine the text that displays if Display Override is enabled.	
Animation	Select the animation of the indicator LEDs from the animation table.	
Color 1	Select the color of the first row of indicator LEDs.	
Color 1 Intensity	Define the intensity of the first row of indicator LEDs.	
Configuration Speed	Define the speed of the animation.	
Pulse Pattern	Select the pulse pattern of the indicator LEDs: Normal, Strobe, Three Pulse, SOS, or Random.	
Color 2	Select the color of the first row of indicator LEDs.	
Color 2 Intensity	Define the intensity of the first row of indicator LEDs.	

### Measure Mode Settings

Use the Process Data to display the measurement values. Options include either the raw input values or the scaled values.

Parameters: Measure Mode Settings				
Measure General Configuration.Filtering	rw	Off		
Measure General Configuration.Hysteresis	rw	Off		
Measure General Configuration.Measure/Timer/Counter Mode Data Label	rw			
Measure General Configuration.Measure/Timer/Counter Mode Value	rw	Enabled		
Measure General Configuration.Measure/Timer/Counter Mode Bar Graph	rw	Enabled		
Measure General Configuration.Output Scale Value Low	rw	0		
Measure General Configuration.Output Scale Value High	rw	10		
Measure General Configuration.Input Scale Value Low	rw	0		
Measure General Configuration.Input Scale Value High	rw	65535		
Measure General Configuration.Measure/Timer/Counter Mode Value Label	rw			
Measure General Configuration.Measure/Timer/Counter Mode Display Orientation	rw	0		
Measure General Configuration.Measure/Timer/Counter Mode Display Minimal Bar Graph	rw	Disabled		
Measure General Configuration.Measure/Timer/Counter Mode Decimal Places	rw	1		
Measure General Configuration.Measure/Timer/Counter Mode Display as Time	rw	Disabled		

General Settings	Description
Filtering	The level of filtering used to minimize the effects of noise on the output.
Hysteresis	The level of lag between the measurement thresholds to minimize the flickering at switch points.
Measure/Timer/Counter Mode Data Label	Text that displays before the Count Value.
Measure/Timer/Counter Mode Bar Graph	Display the bar graph across the full display.
Output Scale Value Low	The low-end value of the output translated from the input frequency.
Output Scale Value High	The high-end value of the output translated from the input frequency.
Input Scale Value Low	The lowest frequency of the input range.
Input Scale Value High	The highest frequency of the input range.
Measure/Timer/Counter Mode Value Label	Text that displays after the Count Value to indicate the units displayed. This can be up to three characters.
Measure General Configuration.Measure/Timer/Counter Mode Display Orientation	Determine the orientation of the bar graph, using the connector as a reference.
Measure General Configuration.Measure/Timer/Counter Mode Display Minimal Bar Graph	Display the bar graph as a single line of LEDs.
Measure General Configuration.Measure/Timer/Counter Mode Decimal Places	Determine the number of decimal places displayed on the Count Value.
Measure General Configuration.Measure/Timer/Counter Mode Display as Time	Display the time in HH:MM:SS format without data labels.

### Message Mode

Use Message Mode to create and save thirteen display messages.

Parameters: Message Mode Message Settings			
Message Mode Settings.Message 1	rw	Reset	
Message Mode Settings.Message 2	rw	Fault	
Message Mode Settings.Message 3	rw	Stop	
Message Mode Settings.Message 4	rw	Start	
Message Mode Settings.Message 5	rw	Chageover	
Message Mode Settings.Message 6	rw	Open	
Parameters: Message Mode Message Settings Continued			
Message Mode Settings Continued.Message 7	rw	Welcome	
Message Mode Settings Continued.Message 8	rw	Quality	
Message Mode Settings Continued.Message 9	rw	Warning	
Message Mode Settings Continued.Message 10	rw	Alarm	
Message Mode Settings Continued.Message 11	rw	Break	
Message Mode Settings Continued.Message 12	rw	Run	
Message Mode Settings Continued.Message 13	rw	Maintenance	

### **Threshold Settings**

Use Threshold Settings to configure the thresholds using in Measure Mode, Timer Mode, and Counter Mode. Four of these thresholds can be set individually.

A Parameters: Threshold 1 Settings				
Measure Threshold 1 Configuration. Threshold Enable	rw	Enabled		
Measure Threshold 1 Configuration. Threshold Value	rw	25		
Measure Threshold 1 Configuration. Threshold Comparison	rw	Less Than		
Measure Threshold 1 Configuration. Threshold Override	rw	Disabled		
Measure Threshold 1 Configuration.Display Override	rw	Disabled		
Measure Threshold 1 Configuration.Override string	rw	Thresh 1		
Measure Threshold 1 Configuration.Animation	rw	Steady		
Measure Threshold 1 Configuration.Color 1	rw	Green		
Measure Threshold 1 Configuration.Color 1 Intensity	rw	High		
Measure Threshold 1 Configuration.Speed	rw	Standard		
Measure Threshold 1 Configuration.Pulse Pattern	rw	Normal		
Measure Threshold 1 Configuration.Color 2	rw	Green		
Measure Threshold 1 Configuration.Color 2 Intensity	rw	High		

General Settings	Description	
Threshold Enable	Determine if thresholds will be used to change the output at various levels.	
Threshold Value	Define the percentage of the overall value that sets the threshold based on the threshold number used.	
Threshold Comparison	Determine if this threshold is in use for values greater than or less than the Threshold Value.	
Threshold Override	Determine the precedence of the thresholds that have overlapping criteria.	

General Settings	Description	
Display Override	Determine if the device displays a string of text rather than the output values.	
Override String	Determine the text that displays if Display Override is enabled.	
Animation	Select the animation of the indicator LEDs from the animation table.	
Color	Select the color of the indicator LEDs.	
Color Intensity	Define the intensity of the indicator LEDs.	
Configuration Speed	Define the speed of the animation.	
Pulse Pattern	Select the pulse pattern of the indicator LEDs: Normal, Strobe, Three Pulse, SOS, or Random.	

#### **Timer Mode**

Use Timer Mode to count up to or down from a determined value. For additional timer settings, refer to the table in Measure Mode Settings.

Parameters: Timer Mode Settings			
Timer Mode Settings.Timer Value	rw	15	
Timer Mode Settings.Timer Unit Type	rw	Seconds	
Timer Mode Settings.Timer Count Type	rw	Up	
Timer Mode Settings.Enable Auto Reload	rw	Enabled	

General Settings	Description	
Timer Value	The total time of the timer.	
Timer Unit Type	Select the units of the timer.	
Timer Count Type	Up: Counts up from zero to Count Seconds. Down: Counts down from Count Seconds to zero.	
Enable Auto Reload	The timer loops back to the original value automatically when it reaches its final value.	

### **Counter Mode**

Counter Mode uses parameter settings found in Measure Mode Settings to configure the output of the device. For more detail, refer to the table in Measure Mode Settings.

#### Demo Mode

Demo sequence cycles through twelve different configurations to highlight example applications.

#### **Process Data**

Process Data is used to implement the data to run the device. With Process Data, the selection menu changes based on the Mode Selection written to the device.

Generic		Des sees Data IN	Due	Deta OUT
Process Data		Process Data IN	Name	cess Data OUT Val
Parameters	Name	Val	Increment Count	0
			Reset Count	0
			Keset Count	0
				Write

### Run Mode

Process Data OUT		
Name	Val	
Animation	Off	
Color 1	Green	
Color 1 Intensity	High	
Speed	Slow	
Pulse Pattern	Normal	
Color 2	Green	
Color 2 Intensity	High	
Display Text	@	

### Message Mode

Name	Val
Animation	Off
Color 1	Green
Color 1 Intensity	High
Speed	Slow
Pulse Pattern	Normal
Color 2	Green
Color 2 Intensity	High
Message Selection 1	0
Message Selection 2	4

### Measure Mode

Process [	Data OUT
Name	Val
Measure Mode Value	16384

### Timer Mode

Process Data OUT		
Name	Val	
Run Timer	1	
Reset Timer	0	

### **Counter Mode**

Process Data OUT		
Name	Val	
Increment Count	1	
Reset Count	0	

### **Indicator LED Animations**

Animation	Description	
Off	Indication LEDs are off.	
Steady	Color 1 is solid on at a defined intensity.	
Flash	Color 1 flashes alternately at defined speed, color intensities, and pattern (Normal, Strobe, Three Pulse, SOS, or Random).	
Two Color Flash	Color 1 and Color 2 flash alternately at defined speed, color intensities, and pattern (Normal, Strobe, Three Pulse, SOS, or Random).	
50/50	Color 1 and Color 2 are solid at a defined intensity.	
50/50 Flash	Color 1 and Color 2 flash at a defined speed, color intensity, and pattern (Normal, Strobe, Three Pulse, SOS, or Random).	
Intensity Sweep	Color 1 repeatedly increases and decreases intensity between 0% to 100% at defined speed and color intensity.	
Two Color Sweep	Color 1 and Color 2 define the end values of a line across the color gamut. The light continuously displays a color by moving along the line at the defined speed and color intensities.	

FCC Part 15 Class A for Unintentional Radiators	11
Industry Canada ICES-003(A)	11
Dimensions	12

### Chapter 4

### **Specifications**

#### Supply Voltage

12 V DC to 30 V DC

Use only with a suitable Class 2 power supply (UL) or SELV power supply (CE)

#### Supply Current

550 mA max. at 12 V DC 260 mA max. at 24 V DC 210 mA max. at 30 V DC

#### Connections

150 mm (6 in) PVC-jacketed cable with a 4-pin M12 male quick-disconnect connector

Models with a quick-disconnect connector require a mating cordset

Do not spray cable with high-pressure sprayer or cable damage will result

#### **Operating Temperature**

-20 °C to +50 °C (-4 °F to +122 °F)

#### Storage Temperature

-40 °C to +70 °C (-40 °F to +158 °F)

#### **Environmental Rating**

Rated IP65

Suitable for damp locations per UL 2108

#### Vibration and Mechanical Shock

Meets IEC 60068-2-6 requirements (Vibration: 10 Hz to 55 Hz, 1.0 mm amplitude, 5 minutes sweep, 30 minutes dwell) Meets IEC 60068-2-27 requirements (Shock: 15G 11 ms duration, half sine wave)

#### Construction

Black polycarbonate housing and end caps Internal silicone-encapsulated LEDs Smoky polycarbonate window

#### **Character Limit**

Run Mode: 29 characters All other Modes: 32 characters

#### **Required Overcurrent Protection**



**WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table. Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.

Supply wiring leads < 24 AWG shall not be spliced.

For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (A)	Supply Wiring (AWG)	Required Overcurrent Protection (A)
20	5.0	26	1.0
22	3.0	28	0.8
24	1.0	30	0.5

#### Mounting

M5 and 1/4-20 compatible end caps (not included) Clip brackets for mounting are available

### FCC Part 15 Class A for Unintentional Radiators

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(Part 15.21) Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

### Industry Canada ICES-003(A)

This device complies with CAN ICES-3 (A)/NMB-3(A). Operation is subject to the following two conditions: 1) This device may not cause harmful interference; and 2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la norme NMB-3(A). Le fonctionnement est soumis aux deux conditions suivantes : (1) ce dispositif ne peut pas occasionner d'interférences, et (2) il doit tolérer toute interférence, y compris celles susceptibles de provoquer un fonctionnement non souhaité du dispositif.

### Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise. The measurements provided are subject to change.



Models	L1	L2
SD50300	300 mm (11.81 in)	325 mm (12.8 in)

Chapter Contents	
Cordsets	13
Mounting Brackets	. 13

### Chapter 5

### Accessories

### Cordsets

4-Pin Threaded M12 Cordsets—Double Ended				
Model	Length	Style	Dimensions	Pinout
MQDEC-401SS	0.31 m (1 ft)			Female
MQDEC-402SS	0.6 m (1.97 ft)		40 Typ.	1 2
MQDEC-403SS	0.91 m (2.99 ft)			( )
MQDEC-406SS	1.83 m (6 ft)	M12 x1 4	4-	
MQDEC-410SS	3 m (9.4 ft)	Male Straight/ Female Straight	Ø 14.5 [0.57"] J Ø 14.5 [0.57"] J M12 x 1 Ø 14.5 [0.57"] J	Male 2 3 1 = Brown 2 = White 3 = Blue 4 = Black

### **Mounting Brackets**

<ul> <li>LMBSD50</li> <li>Metal mounting bracket kit</li> <li>Hardware included</li> </ul>	
<ul> <li>LMBSD50MAG</li> <li>Magnetic mounting bracket kit</li> <li>Up to 7.26 kg (16 lb) pull</li> <li>Hardware included</li> </ul>	
<ul> <li>LMBSD50-180S</li> <li>Metal mounting bracket kit with 180-degree rotation</li> <li>Stainless steel</li> <li>Hardware included</li> </ul>	

### LMBSD50-180SMAG

- Magnetic mounting bracket kit with 180-degree rotation
- Stainless steel
- Up to 7.26 kg (16 lb) pull
- Hardware included



UTF-8 Encoding Table and Unicode Characters	. 15
Clean with Mild Detergent and Water	. 19
Repairs	. 19
Contact Us	20
Banner Engineering Corp Limited Warranty	20

### Chapter 6

### **Product Support and Maintenance**

### UTF-8 Encoding Table and Unicode Characters

Unicode Code Point	Character	UTF-8 (hex.)	Name
U+0020		20	SPACE
U+0021	!	21	EXCLAMATION MARK
U+0022	"	22	QUOTATION MARK
U+0023	#	23	NUMBER SIGN
U+0024	\$	24	DOLLAR SIGN
U+0025	%	25	PERCENT SIGN
U+0026	&	26	AMPERSAND
U+0027	•	27	APOSTROPHE
U+0028	(	28	LEFT PARENTHESIS
U+0029	)	29	RIGHT PARENTHESIS
U+002A	*	2a	ASTERISK
U+002B	+	2b	PLUS SIGN
U+002C	3	2c	СОММА
U+002D	-	2d	HYPHEN-MINUS
U+002E		2e	FULL STOP
U+002F	1	2f	SOLIDUS
U+0030	0	30	DIGIT ZERO
U+0031	1	31	DIGIT ONE
U+0032	2	32	DIGIT TWO
U+0033	3	33	DIGIT THREE
U+0034	4	34	DIGIT FOUR
U+0035	5	35	DIGIT FIVE
U+0036	6	36	DIGIT SIX
U+0037	7	37	DIGIT SEVEN
U+0038	8	38	DIGIT EIGHT
U+0039	9	39	DIGIT NINE
U+003A	:	За	COLON
U+003B	• ,	3b	SEMICOLON
U+003C	<	3c	LESS-THAN SIGN
U+003D	=	3d	EQUALS SIGN
U+003E	>	3e	GREATER-THAN SIGN
	-	Continued on page 16	

Continued on page 16

Unicode Code Point	Character	Continued from page UTF-8 (hex.)	Name
U+003F	?	3f	QUESTION MARK
U+0040	@	40	COMMERCIAL AT
U+0041	A	41	LATIN CAPITAL LETTER A
U+0042	В	42	LATIN CAPITAL LETTER B
U+0043	C	43	LATIN CAPITAL LETTER C
U+0044	D	44	LATIN CAPITAL LETTER D
U+0045	E	45	LATIN CAPITAL LETTER E
U+0046	F	46	LATIN CAPITAL LETTER F
U+0047	G	47	LATIN CAPITAL LETTER G
U+0048	H	48	LATIN CAPITAL LETTER H
U+0049	1	49	LATIN CAPITAL LETTER I
U+004A	J	4a	LATIN CAPITAL LETTER J
U+004B	К	4b	LATIN CAPITAL LETTER K
U+004C	L	4c	LATIN CAPITAL LETTER L
U+004D	Μ	4d	LATIN CAPITAL LETTER M
U+004E	N	4e	LATIN CAPITAL LETTER N
U+004F	0	4f	LATIN CAPITAL LETTER O
U+0050	Р	50	LATIN CAPITAL LETTER P
U+0051	Q	51	LATIN CAPITAL LETTER Q
U+0052	R	52	LATIN CAPITAL LETTER R
U+0053	S	53	LATIN CAPITAL LETTER S
U+0054	Т	54	LATIN CAPITAL LETTER T
U+0055	U	55	LATIN CAPITAL LETTER U
U+0056	V	56	LATIN CAPITAL LETTER V
U+0057	W	57	LATIN CAPITAL LETTER W
U+0058	Х	58	LATIN CAPITAL LETTER X
U+0059	Y	59	LATIN CAPITAL LETTER Y
U+005A	Z	5a	LATIN CAPITAL LETTER Z
U+005B	[	5b	LEFT SQUARE BRACKET
U+005C	١	5c	REVERSE SOLIDUS
U+005D	]	5d	RIGHT SQUARE BRACKET
U+005E	٨	5e	CIRCUMFLEX ACCENT
U+005F	_	5f	LOW LINE
U+0060	•	60	GRAVE ACCENT
U+0061	а	61	LATIN SMALL LETTER A
U+0062	b	62	LATIN SMALL LETTER B
U+0063	с	63	LATIN SMALL LETTER C
U+0064	d	64	LATIN SMALL LETTER D
U+0065	е	65	LATIN SMALL LETTER E
U+0066	f	66	LATIN SMALL LETTER F
U+0067	g	67	LATIN SMALL LETTER G
U+0068	h	68	LATIN SMALL LETTER H

page 16 of 21

Unicode Code Point	Character	UTF-8 (hex.)	Name
J+0069	i	69	LATIN SMALL LETTER I
J+006A	j	6a	LATIN SMALL LETTER J
J+006B	k	6b	LATIN SMALL LETTER K
J+006C	1	6c	LATIN SMALL LETTER L
J+006D	m	6d	LATIN SMALL LETTER M
J+006E	n	6e	LATIN SMALL LETTER N
J+006F	0	6f	LATIN SMALL LETTER O
J+0070	р	70	LATIN SMALL LETTER P
J+0071	q	71	LATIN SMALL LETTER Q
J+0072	r	72	LATIN SMALL LETTER R
J+0073	s	73	LATIN SMALL LETTER S
J+0074	t	74	LATIN SMALL LETTER T
J+0075	u	75	LATIN SMALL LETTER U
J+0076	v	76	LATIN SMALL LETTER V
J+0077	w	77	LATIN SMALL LETTER W
J+0078	x	78	LATIN SMALL LETTER X
J+0079	у	79	LATIN SMALL LETTER Y
J+007A	Z	7a	LATIN SMALL LETTER Z
J+007B	{	7b	LEFT CURLY BRACKET
J+007C	1	7c	VERTICAL LINE
J+007D	}	7d	RIGHT CURLY BRACKET
J+007E	~	7e	TILDE
J+00A0		c2 a0	NO-BREAK SPACE
J+00A1	i	c2 a1	INVERTED EXCLAMATION MARK
J+00A2	¢	c2 a2	CENT SIGN
J+00A3	£	c2 a3	POUND SIGN
J+00A4	¤	c2 a4	CURRENCY SIGN
J+00A5	¥	c2 a5	YEN SIGN
J+00A6	1	c2 a6	BROKEN BAR
J+00A7	§	c2 a7	SECTION SIGN
J+00A8		c2 a8	DIAERESIS
J+00A9	©	c2 a9	COPYRIGHT SIGN
J+00AA	а	c2 aa	FEMININE ORDINAL INDICATOR
J+00AB	«	c2 ab	LEFT-POINTING DOUBLE ANGLE QUOTATION MARK
J+00AC	-	c2 ac	NOT SIGN
J+00AD		c2 ad	SOFT HYPHEN
J+00AE	®	c2 ae	REGISTERED SIGN
J+00AF	-	c2 af	MACRON
J+00B0	0	c2 b0	DEGREE SIGN
J+00B1	±	c2 b1	PLUS-MINUS SIGN
J+00B2	2	c2 b2	SUPERSCRIPT TWO
J+00B3	3	c2 b3	SUPERSCRIPT THREE

Unicode Code Point	Character	UTF-8 (hex.)	Name
U+00B4	•	c2 b4	ACUTE ACCENT
U+00B5	μ	c2 b5	MICRO SIGN
U+00B6	¶	c2 b6	PILCROW SIGN
U+00B7		c2 b7	MIDDLE DOT
U+00B8	3	c2 b8	CEDILLA
U+00B9	1	c2 b9	SUPERSCRIPT ONE
U+00BA	0	c2 ba	MASCULINE ORDINAL INDICATOR
U+00BB	»	c2 bb	RIGHT-POINTING DOUBLE ANGLE QUOTATION MARK
U+00BC	1/4	c2 bc	VULGAR FRACTION ONE QUARTER
U+00BD	1/2	c2 bd	VULGAR FRACTION ONE HALF
U+00BE	3/4	c2 be	VULGAR FRACTION THREE QUARTERS
U+00BF	ė	c2 bf	INVERTED QUESTION MARK
U+00C0	À	c3 80	LATIN CAPITAL LETTER A WITH GRAVE
U+00C1	Á	c3 81	LATIN CAPITAL LETTER A WITH ACUTE
U+00C2	Â	c3 82	LATIN CAPITAL LETTER A WITH CIRCUMFLEX
U+00C3	Ã	c3 83	LATIN CAPITAL LETTER A WITH TILDE
U+00C4	Ä	c3 84	LATIN CAPITAL LETTER A WITH DIAERESIS
U+00C5	Å	c3 85	LATIN CAPITAL LETTER A WITH RING ABOVE
U+00C6	Æ	c3 86	LATIN CAPITAL LETTER AE
U+00C7	Ç	c3 87	LATIN CAPITAL LETTER C WITH CEDILLA
U+00C8	È	c3 88	LATIN CAPITAL LETTER E WITH GRAVE
U+00C9	É	c3 89	LATIN CAPITAL LETTER E WITH ACUTE
U+00CA	Ê	с3 8а	LATIN CAPITAL LETTER E WITH CIRCUMFLEX
U+00CB	Ë	c3 8b	LATIN CAPITAL LETTER E WITH DIAERESIS
U+00CC	1	c3 8c	LATIN CAPITAL LETTER I WITH GRAVE
U+00CD	í	c3 8d	LATIN CAPITAL LETTER I WITH ACUTE
U+00CE	î	c3 8e	LATIN CAPITAL LETTER I WITH CIRCUMFLEX
U+00CF	ï	c3 8f	LATIN CAPITAL LETTER I WITH DIAERESIS
U+00D0	Ð	c3 90	LATIN CAPITAL LETTER ETH
U+00D1	Ñ	c3 91	LATIN CAPITAL LETTER N WITH TILDE
U+00D2	Ò	c3 92	LATIN CAPITAL LETTER O WITH GRAVE
U+00D3	Ó	c3 93	LATIN CAPITAL LETTER O WITH ACUTE
U+00D4	Ô	c3 94	LATIN CAPITAL LETTER O WITH CIRCUMFLEX
U+00D5	Õ	c3 95	LATIN CAPITAL LETTER O WITH TILDE
U+00D6	Ö	c3 96	LATIN CAPITAL LETTER O WITH DIAERESIS
U+00D7	×	c3 97	MULTIPLICATION SIGN
U+00D8	Ø	c3 98	LATIN CAPITAL LETTER O WITH STROKE
U+00D9	Ù	c3 99	LATIN CAPITAL LETTER U WITH GRAVE
U+00DA	Ú	c3 9a	LATIN CAPITAL LETTER U WITH ACUTE
U+00DB	Û	c3 9b	LATIN CAPITAL LETTER U WITH CIRCUMFLEX
U+00DC	Ü	c3 9c	LATIN CAPITAL LETTER U WITH DIAERESIS
U+00DD	Ý	c3 9d	LATIN CAPITAL LETTER Y WITH ACUTE

UnoceDef CalacterOf the (nex.)Other (nex.)NameU+00DE55LATIN CAPITAL LETTER THORNU+00DF83 a0LATIN SMALL LETTER A WITH GRAVEU+00E143 a1LATIN SMALL LETTER A WITH GRAVEU+00E283 a2LATIN SMALL LETTER A WITH GRAVEU+00E383 a3LATIN SMALL LETTER A WITH GRAVEU+00E483 a3LATIN SMALL LETTER A WITH GRAVEU+00E583 a5LATIN SMALL LETTER A WITH GRAVEU+00E683 a5LATIN SMALL LETTER A WITH CORLUMELEXU+00E583 a5LATIN SMALL LETTER A WITH CORLUAU+00E683 a6LATIN SMALL LETTER A WITH CORLUAU+00E683 a6LATIN SMALL LETTER A WITH CORLUAU+00E683 a6LATIN SMALL LETTER A WITH CORLUAU+00E79C 3 a6LATIN SMALL LETTER A WITH GRAVEU+00E863 a6LATIN SMALL LETTER WITH GRAVEU+00E91C 3 a6LATIN SMALL LETTER WITH ACUTEU+00E11C 3 a6LATIN SMALL LETTER WITH GRAVEU+00E71C 3 a6LATIN SMALL LETTER I WITH GRAVEU+00E71C 3 a6LATIN SMALL LETTER I WITH GRAVEU+00E76C 3 a6LATIN SMALL LETTER I WITH GRAVEU+00E76C 3 a6LATIN SMALL LETTER I WITH GRAVEU+00E76C 3 b6LATIN SMALL LETTER O WITH HIDEU+00F16C 3 b6LATIN SMALL LETTER O WITH HIDEU+00F		Observator	Continued from page 18	Maria
U+00DFBG 3 9LATIN SMALL LETTER SHARP SU+00E14G 3 0LATIN SMALL LETTER A WITH GRAVEU+00E14G 3 1LATIN SMALL LETTER A WITH ACUTEU+00E24G 3 2LATIN SMALL LETTER A WITH ACUTEU+00E36G 3 2LATIN SMALL LETTER A WITH ACUTEU+00E44G 3 2LATIN SMALL LETTER A WITH OLCOUMFLEXU+00E54G 3 4LATIN SMALL LETTER A WITH DAERESISU+00E68G 3 6LATIN SMALL LETTER A WITH AURCOVEU+00E7CG 3 6LATIN SMALL LETTER CWITH COLLLAU+00E86G 3 8LATIN SMALL LETTER E WITH ACUTEU+00E96G 3 8LATIN SMALL LETTER E WITH CRAVEU+00E96G 3 8LATIN SMALL LETTER E WITH ACUTEU+00E96G 3 8LATIN SMALL LETTER E WITH ACUTEU+00E96G 3 8LATIN SMALL LETTER E WITH ACUTEU+00E91G 3 8LATIN SMALL LETTER E WITH ACUTEU+00E91G 3 8LATIN SMALL LETTER I WITH ACUTEU+00E91G 3 8LATIN SMALL LETTER I WITH ACUTEU+00E96G 3 8LATIN SMALL LETTER I WITH ACUTEU+00E96G 3 8LATIN SMALL LETTER I WITH ACUTEU+00F11G 3 6LATIN SMALL LETTER I WITH ACUTEU+00F26G 3 6LATIN SMALL LETTER O WITH GRAVEU+00F36G 3 6LATIN SMALL LETTER O WITH GRAVEU+00F46G 3 6LATIN SMALL LETTER O WITH GRAVEU	Unicode Code Point	Character	UTF-8 (hex.)	Name
u+00E0àG3 a0LATIN SMALL LETTER A WITH GRAVEu+00E1àG3 a1LATIN SMALL LETTER A WITH ACUTEu+00E2àG3 a2LATIN SMALL LETTER A WITH CIRCUMFLEXu+00E3àG3 a3LATIN SMALL LETTER A WITH CIRCUMFLEXu+00E4àG3 a4LATIN SMALL LETTER A WITH TILDEu+00E5àG3 a4LATIN SMALL LETTER A WITH DIAERESISu+00E6àG3 a6LATIN SMALL LETTER A WITH RING ABOVEu+00E6àG3 a7LATIN SMALL LETTER WITH COILLAu+00E7çG3 a7LATIN SMALL LETTER WITH GRAVEu+00E8àG3 a9LATIN SMALL LETTER WITH GRAVEu+00E8éG3 a9LATIN SMALL LETTER WITH GRAVEu+00E8éG3 a0LATIN SMALL LETTER WITH GRAVEu+00E9éG3 a2LATIN SMALL LETTER WITH GRAVEu+00E11G3 a6LATIN SMALL LETTER WITH GRAVEu+00E21G3 a6LATIN SMALL LETTER WITH GRAVEu+00E51G3 a6LATIN SMALL LETTER WITH GRAVEu+00E11G3 a6LATIN SMALL LETTER WITH GRAVEu+00E56G3 b1LATIN SMALL LETTER WITH GRAVEu+00F16G3 b1LATIN SMALL LETTER O WITH GRAVEu+00F26G3 b1LATIN SMALL LETTER O WITH GRAVEu+00F36G3 b1LATIN SMALL LETTER O WITH GRAVEu+00F46G3 b1LATIN SMALL LETTER O WITH GRAVEu+00F56G3 b1LATIN SMALL LETTER O WITH GRAVEu+00F4 </td <td></td> <td></td> <td></td> <td></td>				
U+00E1âG 3 a1LATIN SMALL LETTER A WITH ACUTEU+00E2âG 3 a2LATIN SMALL LETTER A WITH CIRCUMFLEXU+00E3âG 3 a3LATIN SMALL LETTER A WITH DIAEU+00E4âG 3 a4LATIN SMALL LETTER A WITH DIAEU+00E5âG 3 a5LATIN SMALL LETTER A WITH DIAEU+00E6aG 3 a6LATIN SMALL LETTER A WITH DIAEU+00E7çG 3 a6LATIN SMALL LETTER A WITH CEDILLAU+00E8éG 3 a7LATIN SMALL LETTER E WITH CEDILLAU+00E9éG 3 a7LATIN SMALL LETTER E WITH ACUTEU+00E9éG 3 a9LATIN SMALL LETTER E WITH ACUTEU+00E9éG 3 a9LATIN SMALL LETTER E WITH ACUTEU+00E9éG 3 a0LATIN SMALL LETTER E WITH ACUTEU+00E9íG 3 a6LATIN SMALL LETTER E WITH ACUTEU+00E1íG 3 a6LATIN SMALL LETTER I WITH ACUTEU+00E2íG 3 a6LATIN SMALL LETTER I WITH ACUTEU+00E4íG 3 a6LATIN SMALL LETTER I WITH ACUTEU+00E5íG 3 b1LATIN SMALL LETTER I WITH ACUTEU+00F1ñG 3 b1LATIN SMALL LETTER O WITH GRAVEU+00F2íG 3 b1LATIN SMALL LETTER O WITH GRAVEU+00F3íG 3 b1LATIN SMALL LETTER O WITH GRAVEU+00F4íG 3 b6LATIN SMALL LETTER O WITH GRAVEU+00F5íG 3 b6LATIN SMALL LETTER O WITH GRAVEU+00F4íG 3 b6LATIN SMALL LETTER O WITH G				
U+00E2aG3 a2LATIN SMALL LETTER A WITH CIRCUMFLEXU+00E3aG3 a3LATIN SMALL LETTER A WITH TILDEU+00E4aG3 a4LATIN SMALL LETTER A WITH DIAERESISU+00E5aG3 a6LATIN SMALL LETTER A WITH RING ABOVEU+00E6æG3 a6LATIN SMALL LETTER A WITH RING ABOVEU+00E7ÇG3 a7LATIN SMALL LETTER A WITH GRAVEU+00E8êG3 a6LATIN SMALL LETTER C WITH GRAVEU+00E96G3 a6LATIN SMALL LETTER E WITH GRAVEU+00E8êG3 a6LATIN SMALL LETTER E WITH GRAVEU+00E8êG3 a6LATIN SMALL LETTER E WITH GRAVEU+00E8êG3 a6LATIN SMALL LETTER I WITH GRAVEU+00E91G3 a6LATIN SMALL LETTER I WITH GRAVEU+00E61G3 a6LATIN SMALL LETTER I WITH GRAVEU+00E71G3 a6LATIN SMALL LETTER I WITH GRAVEU+00E71G3 a6LATIN SMALL LETTER I WITH GRAVEU+00E76G3 b1LATIN SMALL LETTER O WITH GRAVEU+00F36G3 b2LATIN SMALL LETTER O WITH GRAVEU+00F46G3 b6LATIN SMALL LETTER O WITH GRAVEU+00F56G3 b6LATIN SMALL LETTER O WITH GRAVEU+00F66G3 b6LATIN SMALL LETTER O WITH GRAVE	U+00E0	à		
u+0063á6 a ac a aLATIN SMALL LETTER A WITH TILDEU+00E4ác a ac a aLATIN SMALL LETTER A WITH DIAERESISU+00E5ác a ac a aLATIN SMALL LETTER A WITH RING ABOVEU+00E7çc a aLATIN SMALL LETTER C WITH CEDILAU+00E7çc a aLATIN SMALL LETTER C WITH CRAVEU+00E7çc a aLATIN SMALL LETTER C WITH ACUTEU+00E8éc a aLATIN SMALL LETTER E WITH ACUTEU+00E8éc a aLATIN SMALL LETTER WITH ACUTEU+00E9íc a aLATIN SMALL LETTER WITH DIAERESISU+00E4íc a aLATIN SMALL LETTER WITH DIAERESISU+00E5íc a aLATIN SMALL LETTER I WITH DIAERESISU+00E6íc a aLATIN SMALL LETTER I WITH DIAERESISU+00E7íc a aLATIN SMALL LETTER I WITH DIAERESISU+00E7íc a aLATIN SMALL LETTER I WITH DIAERESISU+00E7íc a bLATIN SMALL LETTER I WITH DIAERESISU+00F1ñc b ac bU+00F2óc b aLATIN SMALL LETTER O WITH ACUTEU+00F3íc b aLATIN SMALL LETTER O WITH ACUTEU+00F4íc b bLATIN SMALL LETTER O WITH ACUTEU+00F5íc b bLATIN SMALL LETTER O WITH ACUTEU+00F4íc b bLATIN SMALL LETTER O WITH ACUTEU+00F5íc b bLATIN SMALL LETTER O WITH ACUTEU+00F4íc b bLATIN SMA	U+00E1	á	c3 a1	LATIN SMALL LETTER A WITH ACUTE
u+0064aacau+00E5áccacc	U+00E2	â	c3 a2	LATIN SMALL LETTER A WITH CIRCUMFLEX
U+00E5á63 a5LATIN SMALL LETTER A WITH RING ABOVEU+00E6æ3 a6LATIN SMALL LETTER AU+00E7ç3 a7LATIN SMALL LETTER C WITH CEDILLAU+00E8é3 a8LATIN SMALL LETTER E WITH GRAVEU+00E9é3 a8LATIN SMALL LETTER E WITH CIRCUMFLEXU+00E4é3 a8LATIN SMALL LETTER E WITH CIRCUMFLEXU+00E5é3 a8LATIN SMALL LETTER E WITH CIRCUMFLEXU+00E613 a6LATIN SMALL LETTER E WITH CIRCUMFLEXU+00E713 a6LATIN SMALL LETTER I WITH GRAVEU+00E613 a6LATIN SMALL LETTER I WITH CIRCUMFLEXU+00E713 a6LATIN SMALL LETTER I WITH CIRCUMFLEXU+00E713 a6LATIN SMALL LETTER I WITH CIRCUMFLEXU+00F1ñ3 b1LATIN SMALL LETTER I WITH CIRCUMFLEXU+00F263 b1LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F363 b1LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F463 b6LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F563 b6LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F663 b6LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F663 b6LATIN SMALL LETTER O WITH STROKEU+00F663 b6LAT	U+00E3	ã	c3 a3	LATIN SMALL LETTER A WITH TILDE
U+00E6aeG3 a6LATIN SMALL LETTER AEU+00E7ÇG3 a7LATIN SMALL LETTER C WITH CEDILLAU+00E8éG3 a8LATIN SMALL LETTER E WITH GRAVEU+00E9éG3 a9LATIN SMALL LETTER E WITH ACUTEU+00E4éG3 a8LATIN SMALL LETTER E WITH ACUTEU+00E5éG3 a6LATIN SMALL LETTER E WITH DIAERESISU+00E6iG3 a6LATIN SMALL LETTER I WITH DIAERESISU+00E7iG3 a6LATIN SMALL LETTER I WITH ACUTEU+00E6iG3 a6LATIN SMALL LETTER I WITH ACUTEU+00E7iG3 a6LATIN SMALL LETTER I WITH DIAERESISU+00E6iG3 a6LATIN SMALL LETTER I WITH DIAERESISU+00E7iG3 a6LATIN SMALL LETTER I WITH DIAERESISU+00E7iG3 b1LATIN SMALL LETTER OWITH ACUTEU+00F1nG3 b1LATIN SMALL LETTER OWITH ACUTEU+00F2iG3 b2LATIN SMALL LETTER OWITH ACUTEU+00F3iG3 b3LATIN SMALL LETTER OWITH ACUTEU+00F4iG3 b5LATIN SMALL LETTER OWITH DIAERESISU+00F5iG3 b6LATIN SMALL LETTER OWITH STROKEU+00F6iG3 b6LATIN SMALL LETTER OWITH STROKE <t< td=""><td>U+00E4</td><td>ä</td><td>c3 a4</td><td>LATIN SMALL LETTER A WITH DIAERESIS</td></t<>	U+00E4	ä	c3 a4	LATIN SMALL LETTER A WITH DIAERESIS
U+00E7çG3 a7LATIN SMALL LETTER C WITH CEDILLAU+00E8éG3 a8LATIN SMALL LETTER E WITH GRAVEU+00E9éG3 a9LATIN SMALL LETTER E WITH ACUTEU+00EAéG3 a0LATIN SMALL LETTER E WITH CIRCUMFLEXU+00EBéG3 acLATIN SMALL LETTER E WITH DIAERESISU+00ECiG3 acLATIN SMALL LETTER I WITH GRAVEU+00EFiG3 adLATIN SMALL LETTER I WITH ACUTEU+00EFiG3 acLATIN SMALL LETTER I WITH CIRCUMFLEXU+00EFiG3 adLATIN SMALL LETTER I WITH CIRCUMFLEXU+00F1ñG3 b1LATIN SMALL LETTER I WITH DIAERESISU+00F2ôG3 b2LATIN SMALL LETTER O WITH ACUTEU+00F3ôG3 b2LATIN SMALL LETTER O WITH GRAVEU+00F4ôG3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5ôG3 b5LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6ôG3 b6LATIN SMALL LETTER O WITH FILDEU+00F76G3 b6LATIN SMALL LETTER O WITH STROKEU+00F80G3 b6LATIN SMALL LETTER O WITH STROKEU+00F90G3 b6LATIN SMALL LETTER O WITH ACUTEU+00F66G3 b6LATIN SMALL LETTER O WITH STROKEU+00F76G3 b6LATIN SMALL LETTER O WITH STROKEU+00F80G3 b6LATIN SMALL LETTER U WITH GRAVEU+00F90G3 b6LATIN SMALL LETTER U WITH GRAVEU+00F80G3 b6LATIN SMALL LETT	U+00E5	å	c3 a5	LATIN SMALL LETTER A WITH RING ABOVE
u         o	U+00E6	æ	c3 a6	LATIN SMALL LETTER AE
U+00E9éc3 a9LATIN SMALL LETTER E WITH ACUTEU+00EAéc3 aaLATIN SMALL LETTER E WITH CIRCUMFLEXU+00EBéc3 abLATIN SMALL LETTER E WITH DIAERESISU+00EC1c3 acLATIN SMALL LETTER I WITH GRAVEU+00EDíc3 adLATIN SMALL LETTER I WITH ACUTEU+00EFíc3 adLATIN SMALL LETTER I WITH ACUTEU+00EFíc3 afLATIN SMALL LETTER I WITH ACUTEU+00F1ñc3 b1LATIN SMALL LETTER NWITH TILDEU+00F2óc3 b1LATIN SMALL LETTER O WITH GRAVEU+00F3óc3 b2LATIN SMALL LETTER O WITH ACUTEU+00F4óc3 b4LATIN SMALL LETTER O WITH ACUTEU+00F5óc3 b5LATIN SMALL LETTER O WITH ACUTEU+00F6óc3 b6LATIN SMALL LETTER O WITH ACUTEU+00F7ic3 b6LATIN SMALL LETTER O WITH ACUTEU+00F8úc3 b6LATIN SMALL LETTER O WITH ACUTEU+00F9úc3 b6LATIN SMALL LETTER O WITH ACUTEU+00F4úc3 b6LATIN SMALL LETTER O WITH ACUTEU+00F5úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F8úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6úc3 b6LATIN SMALL LETTER U WITH ACUTE <t< td=""><td>U+00E7</td><td>Ç</td><td>c3 a7</td><td>LATIN SMALL LETTER C WITH CEDILLA</td></t<>	U+00E7	Ç	c3 a7	LATIN SMALL LETTER C WITH CEDILLA
U+00EAéc3 aaLATIN SMALL LETTER E WITH CIRCUMFLEXU+00EBéc3 abLATIN SMALL LETTER E WITH DIAERESISU+00ECic3 acLATIN SMALL LETTER I WITH GRAVEU+00EDíc3 adLATIN SMALL LETTER I WITH GRAVEU+00EDíc3 adLATIN SMALL LETTER I WITH ACUTEU+00EFíc3 afLATIN SMALL LETTER I WITH CIRCUMFLEXU+00F0óc3 bdLATIN SMALL LETTER I WITH DIAERESISU+00F1ñc3 bdLATIN SMALL LETTER NWITH TILDEU+00F2óc3 bdLATIN SMALL LETTER O WITH GRAVEU+00F3óc3 bdLATIN SMALL LETTER O WITH ACUTEU+00F4óc3 bdLATIN SMALL LETTER O WITH ACUTEU+00F5óc3 bdLATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6óc3 bdLATIN SMALL LETTER O WITH ACUTEU+00F7÷c3 bdLATIN SMALL LETTER O WITH ACUTEU+00F8óc3 bdLATIN SMALL LETTER O WITH ACUTEU+00F9úc3 bdLATIN SMALL LETTER O WITH ACUTEU+00FAúc3 bdLATIN SMALL LETTER U WITH ACUTE </td <td>U+00E8</td> <td>è</td> <td>c3 a8</td> <td>LATIN SMALL LETTER E WITH GRAVE</td>	U+00E8	è	c3 a8	LATIN SMALL LETTER E WITH GRAVE
U+00EBéc3 abLATIN SMALL LETTER E WITH DIAERESISU+00ECic3 acLATIN SMALL LETTER I WITH GRAVEU+00EDic3 adLATIN SMALL LETTER I WITH GRAVEU+00EEic3 acLATIN SMALL LETTER I WITH CUTEU+00EFic3 acLATIN SMALL LETTER I WITH DIAERESISU+00EFic3 adLATIN SMALL LETTER I WITH DIAERESISU+00F1ic3 bdLATIN SMALL LETTER I WITH DIAERESISU+00F2oc3 bdLATIN SMALL LETTER N WITH TIDEU+00F3oc3 bdLATIN SMALL LETTER O WITH GRAVEU+00F4oc3 bdLATIN SMALL LETTER O WITH GRAVEU+00F5oc3 bdLATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6oc3 bdLATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6oc3 bdLATIN SMALL LETTER O WITH DIAERESISU+00F6oc3 bdLATIN SMALL LETTER O WITH STROKEU+00F6oc3 bdLATIN SMALL LETTER O WITH STROKEU+00F6oc3 bdLATIN SMALL LETTER O WITH STROKEU+00F6oc3 bdLATIN SMALL LETTER U WITH GRAVEU+00F6oc3 bdLATIN SMALL LETTER U WITH GRAVEU+00F6oc3 bdLATIN SMALL LETTER U WITH GRAVEU+00F6oc3 bdLATIN SMALL LETTER U WITH CIRCUMFLEXU+00F6oc3 bdLATIN SMALL LETTER U WITH CIRCUMFLEXU+00F6oc3 bdLATIN SMALL LETTER U WITH CIRCUMFLEXU+00F6oc3 bdLATIN SMA	U+00E9	é	c3 a9	LATIN SMALL LETTER E WITH ACUTE
U+00ECic3 acLATIN SMALL LETTER I WITH GRAVEU+00EDic3 adLATIN SMALL LETTER I WITH ACUTEU+00EFic3 afLATIN SMALL LETTER I WITH CIRCUMFLEXU+00EFic3 afLATIN SMALL LETTER I WITH DIAERESISU+00F0ôc3 b0LATIN SMALL LETTER I WITH DIAERESISU+00F1ñc3 b1LATIN SMALL LETTER N WITH TILDEU+00F2ôc3 b2LATIN SMALL LETTER O WITH GRAVEU+00F3ôc3 b3LATIN SMALL LETTER O WITH GRAVEU+00F4ôc3 b4LATIN SMALL LETTER O WITH ACUTEU+00F5ôc3 b5LATIN SMALL LETTER O WITH DIAERESISU+00F6ôc3 b4LATIN SMALL LETTER O WITH DIAERESISU+00F7\$c3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F8ôc3 b3LATIN SMALL LETTER O WITH DIAERESISU+00F91c3 b4LATIN SMALL LETTER O WITH STROKEU+00F41c3 b4LATIN SMALL LETTER O WITH STROKEU+00F51c3 b3LATIN SMALL LETTER U WITH ACUTEU+00F61c3 b4LATIN SMALL LETTER U WITH ACUTEU+00F81c3 b4LATIN SMALL LETTER U WITH CIRCUMFLEXU+00F61c3 b4 <td< td=""><td>U+00EA</td><td>ê</td><td>с3 аа</td><td>LATIN SMALL LETTER E WITH CIRCUMFLEX</td></td<>	U+00EA	ê	с3 аа	LATIN SMALL LETTER E WITH CIRCUMFLEX
U+00EDíiiiiU+00EAiii	U+00EB	ë	c3 ab	LATIN SMALL LETTER E WITH DIAERESIS
U+00EĨC3 aeLATIN SMALL LETTER I WITH CIRCUMFLEXU+00EFĨC3 afLATIN SMALL LETTER I WITH DIAERESISU+00F0ÔC3 b0LATIN SMALL LETTER I WITH DIAERESISU+00F1ÑC3 b1LATIN SMALL LETTER N WITH TILDEU+00F2ÔC3 b2LATIN SMALL LETTER O WITH GRAVEU+00F3ÔC3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4ÔC3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5ÔC3 b5LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6ÔC3 b5LATIN SMALL LETTER O WITH DIAERESISU+00F7\$C3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F8ÔC3 b7DIVISION SIGNU+00F9ÔC3 b8LATIN SMALL LETTER O WITH GRAVEU+00F4ÔC3 b4LATIN SMALL LETTER O WITH GRAVEU+00F5ÔC3 b8LATIN SMALL LETTER O WITH GRAVEU+00F6ÔC3 b8LATIN SMALL LETTER U WITH GRAVEU+00F6ÔC3 b8LATIN SMALL LETTER U WITH CIRCUMFLEXU+00F0ÔC3 b6LATIN SMALL LETTER U WITH CIRCUMFLEXU+00F1ÓC3 b6LATIN SMALL LETTER U WITH ACUTEU+00F2ÔC3 b6LATIN SMALL LETTER U WITH ACUTEU+00F3ÓC3 b6LATIN SMALL LETTER U WITH ACUTEU+00F4ÓC3 b6LATIN SMALL LETTER U WITH ACUTEU+00F5ÓC3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6ÓS3 b6LATIN SMALL LETTER U WITH ACUTE </td <td>U+00EC</td> <td>ì</td> <td>c3 ac</td> <td>LATIN SMALL LETTER I WITH GRAVE</td>	U+00EC	ì	c3 ac	LATIN SMALL LETTER I WITH GRAVE
U+00EFic3 afLATIN SMALL LETTER I WITH DIAERESISU+00F0ôc3 b0LATIN SMALL LETTER ETHU+00F1ñc3 b1LATIN SMALL LETTER N WITH TILDEU+00F2ôc3 b2LATIN SMALL LETTER O WITH GRAVEU+00F3óc3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4ôc3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5óc3 b5LATIN SMALL LETTER O WITH TILDEU+00F6ôc3 b6LATIN SMALL LETTER O WITH TILDEU+00F7ic3 b7DIVISION SIGNU+00F8oc3 b8LATIN SMALL LETTER O WITH GRAVEU+00F9úc3 b9LATIN SMALL LETTER O WITH GRAVEU+00F4úc3 b4LATIN SMALL LETTER O WITH GRAVEU+00F5úc3 b8LATIN SMALL LETTER O WITH GRAVEU+00F6úc3 b8LATIN SMALL LETTER O WITH GRAVEU+00F7úc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F8úc3 b8LATIN SMALL LETTER U WITH ACUTEU+00F9úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F0úc3 b6LATIN SMALL LETTER U WITH DIAERESISU+00F1úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F2úc3 b6LATIN SMALL LETTER U WITH ACUTEU+00F2ú <td>U+00ED</td> <td>í</td> <td>c3 ad</td> <td>LATIN SMALL LETTER I WITH ACUTE</td>	U+00ED	í	c3 ad	LATIN SMALL LETTER I WITH ACUTE
U+00F0ôc3 b0LATIN SMALL LETTER THU+00F1ñc3 b1LATIN SMALL LETTER N WITH TILDEU+00F2ôc3 b2LATIN SMALL LETTER O WITH GRAVEU+00F3óc3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4ôc3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5óc3 b5LATIN SMALL LETTER O WITH TILDEU+00F6ôc3 b5LATIN SMALL LETTER O WITH DIAERESISU+00F7óc3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F8øc3 b7DIVISION SIGNU+00F9úc3 b8LATIN SMALL LETTER O WITH STROKEU+00F4úc3 b9LATIN SMALL LETTER U WITH GRAVEU+00F5úc3 b8LATIN SMALL LETTER U WITH ACUTEU+00F6úc3 b1LATIN SMALL LETTER U WITH ACUTEU+00F6úc3 b2LATIN SMALL LETTER U WITH CIRCUMFLEXU+00F6úc3 b2LATIN SMALL LETTER U WITH DIAERESISU+00F6úc3 b2LATIN SMALL LETTER U WITH DIAERESISU+00F6úc3 b2LATIN SMALL LETTER U WITH DIAERESISU+00F6ýc3 b2LATIN SMALL LETTER U WITH ACUTEU+00F6ýc3 b2LATIN SMALL LETTER U WITH ACUTEU+0	U+00EE	î	c3 ae	LATIN SMALL LETTER I WITH CIRCUMFLEX
U+00F1ñG3 b1LATIN SMALL LETTER N WITH TILDEU+00F2ôG3 b2LATIN SMALL LETTER O WITH GRAVEU+00F3óG3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4ôG3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5óG3 b5LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6ôG3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F76G3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F8øG3 b7DIVISION SIGNU+00F9úG3 b8LATIN SMALL LETTER O WITH STROKEU+00F4úG3 b6LATIN SMALL LETTER U WITH GRAVEU+00F5úG3 b8LATIN SMALL LETTER U WITH GRAVEU+00F6úG3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6úG3 b6LATIN SMALL LETTER U WITH DIAERESISU+00F7úG3 b6LATIN SMALL LETTER U WITH DIAERESISU+00F6úG3 b6LATIN SMALL LETTER U WITH DIAERESISU+00F7úG3 b6LATIN SMALL LETTER U WITH DIAERESISU+00F6úG3 b6LATIN SMALL LETTER U WITH DIAERESISU+00F0úG3 b6LATIN SMALL LETTER U WITH ACUTEU+00F0ýG3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6ýG3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6ýG3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6ýG3 b6LATIN SMALL LETTER U WITH ACUTEU+00F6ýS3 b6LATIN SMALL LETTER U WITH ACUTE <td>U+00EF</td> <td>ï</td> <td>c3 af</td> <td>LATIN SMALL LETTER I WITH DIAERESIS</td>	U+00EF	ï	c3 af	LATIN SMALL LETTER I WITH DIAERESIS
U+00F2ôc3 b2LATIN SMALL LETTER O WITH GRAVEU+00F3óc3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4ôc3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5óc3 b5LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F6ôc3 b5LATIN SMALL LETTER O WITH DIAERESISU+00F7*c3 b7DIVISION SIGNU+00F8øc3 b8LATIN SMALL LETTER O WITH STROKEU+00F9ôc3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4ôc3 b4LATIN SMALL LETTER U WITH GRAVEU+00F5óc3 b3LATIN SMALL LETTER U WITH ACUTEU+00F6ôc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F7úc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F8íc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F9úc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F0íc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F1íc3 b4LATIN SMALL LETTER U WITH ACUTEU+00F2ííc3 b4LATIN SMALL LETTER U WITH ACUTE <td< td=""><td>U+00F0</td><td>ð</td><td>c3 b0</td><td>LATIN SMALL LETTER ETH</td></td<>	U+00F0	ð	c3 b0	LATIN SMALL LETTER ETH
U+00F3óc3 b3LATIN SMALL LETTER O WITH ACUTEU+00F4óc3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5óc3 b5LATIN SMALL LETTER O WITH TILDEU+00F6óc3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F7+c3 b7DIVISION SIGNU+00F8øc3 b8LATIN SMALL LETTER O WITH STROKEU+00F9ùc3 b9LATIN SMALL LETTER U WITH GRAVEU+00FAûc3 b4LATIN SMALL LETTER U WITH ACUTEU+00FBûc3 baLATIN SMALL LETTER U WITH ACUTEU+00FCûc3 baLATIN SMALL LETTER U WITH ACUTEU+00FDûc3 baLATIN SMALL LETTER U WITH ACUTEU+00FDúc3 baLATIN SMALL LETTER U WITH ACUTEU+00FDýc3 baLATIN SMALL LETTER U WITH ACUTEU+00FD <td< td=""><td>U+00F1</td><td>ñ</td><td>c3 b1</td><td>LATIN SMALL LETTER N WITH TILDE</td></td<>	U+00F1	ñ	c3 b1	LATIN SMALL LETTER N WITH TILDE
U+00F4ôc3 b4LATIN SMALL LETTER O WITH CIRCUMFLEXU+00F5ôc3 b5LATIN SMALL LETTER O WITH TILDEU+00F6ôc3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F7+c3 b7DIVISION SIGNU+00F8Øc3 b8LATIN SMALL LETTER O WITH STROKEU+00F9ùc3 b9LATIN SMALL LETTER O WITH GRAVEU+00FAúc3 b9LATIN SMALL LETTER U WITH GRAVEU+00FBûc3 baLATIN SMALL LETTER U WITH ACUTEU+00FCûc3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bcLATIN SMALL LETTER U WITH ACUTEU+00FDýc3 bcLATIN SMALL LETTER U WITH ACUTEU+00FD	U+00F2	ò	c3 b2	LATIN SMALL LETTER O WITH GRAVE
U+00F5ôc3 b5LATIN SMALL LETTER O WITH TILDEU+00F6ôc3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F7*c3 b7DIVISION SIGNU+00F8Øc3 b8LATIN SMALL LETTER O WITH STROKEU+00F9ûc3 b9LATIN SMALL LETTER U WITH GRAVEU+00FAúc3 baLATIN SMALL LETTER U WITH ACUTEU+00FBûc3 baLATIN SMALL LETTER U WITH ACUTEU+00FCûc3 baLATIN SMALL LETTER U WITH CIRCUMFLEXU+00FDýc3 baLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bdLATIN SMALL LETTER U WITH ACUTEU+00FDýc3 bdLATIN SMALL LETTER U WITH ACUTEU+00FEýc3 bdLATIN SMALL LETTER U WITH ACUTEU+00FEýc3 bdLATIN SMALL LETTER U WITH ACUTE	U+00F3	ó	c3 b3	LATIN SMALL LETTER O WITH ACUTE
U+00F6ôc3 b6LATIN SMALL LETTER O WITH DIAERESISU+00F7\$c3 b7DIVISION SIGNU+00F8\$c3 b8LATIN SMALL LETTER O WITH STROKEU+00F9\$0c3 b9LATIN SMALL LETTER U WITH GRAVEU+00FA\$\$c3 b8LATIN SMALL LETTER U WITH ACUTEU+00FB\$0c3 b8LATIN SMALL LETTER U WITH ACUTEU+00FC\$\$0c3 b2U+00FD\$\$c3 b2LATIN SMALL LETTER U WITH DIAERESISU+00FD\$\$c3 b2LATIN SMALL LETTER U WITH DIAERESISU+00FD\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FD\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FD\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FE\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FD\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FE\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FE\$\$\$c3 b2LATIN SMALL LETTER U WITH ACUTEU+00FE\$\$\$C3 b2LATIN SMALL LETTER U WITH ACUTEU+00FE\$<	U+00F4	ô	c3 b4	LATIN SMALL LETTER O WITH CIRCUMFLEX
U+00F7÷c3 b7DIVISION SIGNU+00F8Øc3 b8LATIN SMALL LETTER O WITH STROKEU+00F9ûc3 b9LATIN SMALL LETTER U WITH GRAVEU+00FAúc3 baLATIN SMALL LETTER U WITH ACUTEU+00FBûc3 bbLATIN SMALL LETTER U WITH CIRCUMFLEXU+00FCúc3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bdLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bdLATIN SMALL LETTER U WITH ACUTEU+00FDýc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FDýc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FDjc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEjc3 bdLATIN SMALL LETTER Y WITH ACUTE	U+00F5	õ	c3 b5	LATIN SMALL LETTER O WITH TILDE
U+00F8ØC3 b8LATIN SMALL LETTER O WITH STROKEU+00F9ùC3 b9LATIN SMALL LETTER U WITH GRAVEU+00FAúC3 baLATIN SMALL LETTER U WITH ACUTEU+00FBûC3 bbLATIN SMALL LETTER U WITH CIRCUMFLEXU+00FCúC3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýC3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEjC3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FDýC3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEjSabeLATIN SMALL LETTER Y WITH ACUTE	U+00F6	ö	c3 b6	LATIN SMALL LETTER O WITH DIAERESIS
U+00F9úc3 b9LATIN SMALL LETTER U WITH GRAVEU+00FAúc3 baLATIN SMALL LETTER U WITH ACUTEU+00FBûc3 bbLATIN SMALL LETTER U WITH CIRCUMFLEXU+00FCúc3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEjc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FDúc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEjc3 bdLATIN SMALL LETTER Y WITH ACUTE	U+00F7	÷	c3 b7	DIVISION SIGN
U+00FAúc3 baLATIN SMALL LETTER U WITH ACUTEU+00FBûc3 bbLATIN SMALL LETTER U WITH CIRCUMFLEXU+00FCûc3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEjc3 bdLATIN SMALL LETTER Y WITH ACUTE	U+00F8	Ø	c3 b8	LATIN SMALL LETTER O WITH STROKE
U+00FBûc3 bbLATIN SMALL LETTER U WITH CIRCUMFLEXU+00FCûc3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýc3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEþc3 beLATIN SMALL LETTER THORN	U+00F9	ù	c3 b9	LATIN SMALL LETTER U WITH GRAVE
U+00FCüC3 bcLATIN SMALL LETTER U WITH DIAERESISU+00FDýC3 bdLATIN SMALL LETTER Y WITH ACUTEU+00FEþC3 beLATIN SMALL LETTER THORN	U+00FA	ú	c3 ba	LATIN SMALL LETTER U WITH ACUTE
U+00FD     ý     c3 bd     LATIN SMALL LETTER Y WITH ACUTE       U+00FE     p     c3 be     LATIN SMALL LETTER THORN	U+00FB	û	c3 bb	LATIN SMALL LETTER U WITH CIRCUMFLEX
U+00FE p c3 be LATIN SMALL LETTER THORN	U+00FC	ü	c3 bc	LATIN SMALL LETTER U WITH DIAERESIS
U+00FE þ c3 be LATIN SMALL LETTER THORN	U+00FD	ý	c3 bd	LATIN SMALL LETTER Y WITH ACUTE
	U+00FE	þ	c3 be	LATIN SMALL LETTER THORN
	U+00FF		c3 bf	LATIN SMALL LETTER Y WITH DIAERESIS

### Clean with Mild Detergent and Water

Wipe down the enclosure and the display with a soft cloth that has been dampened with a mild detergent and warm water solution.

### Repairs

Contact Banner Engineering for troubleshooting of this device. Do not attempt any repairs to this Banner device; it contains no field-replaceable parts or components. If the device, device part, or device component is determined to be defective by a Banner Applications Engineer, they will advise you of Banner's RMA (Return Merchandise Authorization) procedure.

**IMPORTANT:** If instructed to return the device, pack it with care. Damage that occurs in return shipping is not covered by warranty.

### Contact Us

Banner Engineering Corp. headquarters is located at: 9714 Tenth Avenue North | Plymouth, MN 55441, USA | Phone: + 1 888 373 6767

For worldwide locations and local representatives, visit www.bannerengineering.com.

### Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.



9

<u>LinkedIn</u>

X (formerly Twitter)

<u>Facebook</u>

